


# Typical Wiring Diagram



053-066  
ISSUE 3

DEEP SEA ELECTRONICS

DSE333 A.T.S. CONTROLLER



## ACCESSING THE FRONT PANEL EDITOR (FPE)

- To enter the 'configuration mode' press and hold both the and buttons together.

## EDITING A PARAMETER


- Enter the editor as described above.
- Press to select the required 'page' as detailed overleaf.
- Press + to select the next parameter or - to select the previous parameter within the current page.
- When viewing the parameter to be changed, press the button. The value begins to flash.
- When editing the scheduler, press to move between the various parameters of the scheduler.
- Press + or - to adjust the value to the required setting.
- Press to save the current value, the value ceases flashing.
- Press and hold the button to activate the changes you have made and exit the editor.

TERMINALS SUITABLE FOR 22-16 AWG  
(0.6mm - 1.3mm ) FIELD WIRING  
TIGHTENING TORQUE = 0.8Nm (7lb-in)

## ADJUSTABLE PARAMETERS

When viewing the configuration editor, Press  to select the required 'page' as listed below.

**Front Panel Configuration Editor** (Factory default settings are shown in bold italicised text)

Page	Parameter as shown on display	Values
DISPLAY	Contrast	0% - 100% ( <b>53%</b> )
	Language	<b>English</b> - Others
	Current date and time	Date month year hh:mm:ss
GENERATOR	Under Voltage Trip	50V – 360V ( <b>184V</b> )
	Under Frequency Trip	0Hz - 75Hz ( <b>40Hz</b> )
MAINS	Immediate mains dropout	Active, <b>Inactive</b>
	Under Voltage Trip	50V – 360V ( <b>184V</b> )
	Over Voltage Trip	50V – 360V ( <b>276V</b> )
	Under Frequency Trip	0Hz - 75Hz ( <b>45Hz</b> )
	Over Frequency Trip	0Hz - 75Hz ( <b>55Hz</b> )
TIMERS	Warm Up Time	0 - 1hr ( <b>0s</b> )
	Start Delay	0 - 10hr ( <b>5s</b> )
	Mains Transient Delay	0 - 30s ( <b>2s</b> )
	Generator Failed Delay	0 - 1m ( <b>60s</b> )
	Elevator Delay	0 - 5m (0s)
	Non sync Transfer Time	1 - 10m ( <b>0.7s</b> )
	Check-sync Transfer Time	1 - 10m ( <b>0.2s</b> )
	Return Delay	0 - 5hr ( <b>30s</b> )
	Cool Down Timer	0 - 1hr ( <b>1m</b> )
	Generator Transient Delay	0 - 30s ( <b>0s</b> )
	Fail to Stop Delay	0 - 2m ( <b>30s</b> )
	Scroll Delay	0 - 1hr ( <b>5s</b> )
	Page Timer	0 - 1hr ( <b>5m</b> )
	SCHEDULE	Schedule
Schedule On Load		Active, <b>Inactive</b> (only available when Scheduler is active)
Schedule Period		<b>Weekly</b> , Monthly (only available when Scheduler is active)
Schedule time and date selection (1-16)		Press  when editing to select the different parameters within the scheduler.

 **NOTE:** - More comprehensive configuration is made using the DSE Configuration Suite Software.

 **NOTE:-** To exit the front panel configuration editor and activate your changes, press and hold the  button. Ensure you have saved any changes you have made by pressing the  button first.

## DIMENSIONS AND MOUNTING

For flat surface mounting in a type 1 enclosure and use in a pollution degree 2 environment to meet UL requirements.

### DIMENSIONS

216mm x 158mm x 42mm  
(8.5" x 6.2" x 1.6")

### PANEL CUTOUT

182mm x 137mm  
(7.2" x 5.4")

### WEIGHT

510g (0.51kg)

### FIXING CLIPS

The module is held into the panel fascia using the supplied fixing clips.

- Withdraw the fixing clip screw (turn anticlockwise) until only the pointed end is protruding from the clip.
- Insert the three 'prongs' of the fixing clip into the slots in the side of the 6000 series module case.
- Pull the fixing clip backwards (towards the back of the module) ensuring all three prongs of the clip are inside their allotted slots.
- Turn the fixing clip screws clockwise until they make contact with the panel fascia.

Turn the screws a little more to secure the module into the panel fascia. Care should be taken not to over tighten the fixing clip screws.

 **NOTE:-** In conditions of excessive vibration, mount the panel on suitable anti-vibration mountings.

#### Deep Sea Electronics Plc.

Tel: +44 (0)1723 890099  
Fax: +44 (0)1723 893303  
Telephone 0845 260 8933  
Email: support@deepseapl.com  
Web: www.deepseapl.com

#### Deep Sea Electronics inc.

Phone: +1 (815) 316-8706  
Fax: +1 (815) 316- 8708  
TOLL FREE (USA only)  
Tel: 1 866 636 9703  
Email: support@deepseausa.com  
Web: www.deepseausa.com