

DSE814

AVR USB COMMUNICATIONS INTERFACE

The DSE814 provides an interface between the AVR and a PC, allowing access to the AVR settings via the DSE Configuration Suite PC Software

THE KIT INCLUDES:

- DSE814 interface
- USB lead
- Connection cables



ENVIRONMENTAL TESTING STANDARDS

ELECTRICAL SAFETY

BS EN 60950
Safety of Information Technology Equipment, including Electrical Business Equipment

SPECIFICATION

DC SUPPLY

Powered from the USB connection

OPERATING TEMPERATURE RANGE

-30 °C to +70 °C
-22 °F to +158 °F

DIMENSIONS

90 mm x 50 mm x 25 mm
3.5" x 2" x 1"



RELATED MATERIALS

TITLE

DSEA106 Data Sheet
DSEA106 Installation Instructions
DSEA106 Operator Manual
DSEA106 Configuration Suite PC Software Manual

PART NO'S

055-196
053-177
057-241
057-242

DEEP SEA ELECTRONICS PLC UK

Highfield House, Hunmanby Industrial Estate, Hunmanby YO14 0PH
TELEPHONE +44 (0) 1723 890099 **FACSIMILE** +44 (0) 1723 893303
EMAIL sales@deepseapl.com **WEBSITE** www.deepseapl.com

DEEP SEA ELECTRONICS INC USA

3230 Williams Avenue, Rockford, IL 61101-2668 USA
TELEPHONE +1 (815) 316 8706 **FACSIMILE** +1 (815) 316 8708
EMAIL sales@deepseausa.com **WEBSITE** www.deepseausa.com